Finishing

CLIENT

Leather Goods

RECIPE NO. BU 6197

ARTICLE N°7 BLACK KNIFE BASED ON WE RECIPE NO.

MATERIAL 1/2 BOVINE full grain DATE 11.04.2024
COLOUR TPX 19-1101 TECHNICIAN Giorgio Giraudo

Product	1	2	3	4	5	6	Procedure
PRESKIN	1			ļ		ļ	DRY MILL 8 hrs BEFORE FINISHING
AQUADERM® Finish HAT	600		ļ	ļi		İ	TOGGLE
AQUADERM®Matt 102	300		i	<u> </u>	ļ	İ	10001
BAYDERM®Bottom DLV-N	100		<u> </u>	İ	İ	İ	. <u> </u>
RODA® Lite Black SH	100		<u> </u>	<u> </u>			Preskin:
RODA® Poliperl Iridescent Blue	40		<u> </u>		ļ	ļ	ON RELEASE PAPER "KOMET 234"
water	250		<u> </u>	 		<u> </u>	3 gr. sqft
ACRYSOL™ RM 819W	х				ļ		
Viscosity 30-35 sec , cup 4 mm						ļ	
ADHESIVE							
RODA® Line Base AFG	1000					Ī	Adhesive: (8-9 g./sq.ft)
AQUADERM® FLUID H	10		[1X SPRAY ON LEATHER
RODA® Lite Black SH	100		Í				8 - 9 gr. sqft
AQUADERM® XL 50	50		[
ACRYSOL™ RM 819W	х						
Viscosity 40-45 sec,cup 4 mm			-		<u> </u>	<u> </u>	
FINISHING BY SPRAY	1	i		<u> </u>		ļ	. I
RODA® Lite Black SH	1		30	T			3) 2X SPRAY
RODA® Poliperl Iridescent Blue	1		10				
RODA® Bind TLC 385			70	150			
RODA® Wax 4077/N			30				4) 2X SPRAY
RODA® Pure Lustre 1430	Ī		50			İ	IRON 100°C - 20 BAR
water			610	530			
RODA® Pur 5427/N			100				
BAYDERM®Bottom 10UD			100				
RODA®Link Pax				20			
RODA®Wax KCF 699				50		İ	
RODA®Fix 5188/ N Gloss	i I		(250			
	i i			T		<u> </u>	
			[
	1						
	1		ļ	 		ļ	
	1		i	İ		t	
	!		<u> </u>	ļ	İ	İ	
				<u> </u>		<u> </u>	
Total			Γ '		Γ '	0	

Comments:

RODA® is a registered or filed trademark, owned by or licensed to TFL in most countries.

Our application recommendations are in line with our present state of knowledge. They do not, however, exempt the customer from performing his own tests to determine the suitability of the supplied products for their intended purpose. Application of the products lies outside the scope of our control and therefore comes within the customer's sphere of responsibility.

We guarantee the satisfactory quality of our products subject to our general terms of sale and delivery.

